

# Host Facility Background Job Aid

To be completed at an interval defined by the Public Health Liaison.

To conduct background readings:

- CD V-700P to “X1” scale (0-300 CPM). Remove the plastic cover, making sure the probe window is facing up, and read the Counts Per Minute (CPM) scale for 15 seconds.
- For the M26-1 Frisker remove the pancake protective cover and turn on using OK button. Verify display comes up in CPM mode.

Take the highest reading and record this reading below. If it reads  $\geq 300$  CPM notify the team lead and ensure that the Public Health Liaison has been notified.

<u>Date</u>	<u>Time</u>	<u>Reading</u>
_____	_____	_____
_____	_____	_____
_____	_____	_____
_____	_____	_____
_____	_____	_____
_____	_____	_____
_____	_____	_____
_____	_____	_____
_____	_____	_____
_____	_____	_____
_____	_____	_____
_____	_____	_____